




TOP AND CONSOLE PARTS


For Model: WGD5100SQ0
(Designer White)

29" GAS DRYER



Literature Parts

WIRING HARNESS PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: WGD5100SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8578183	Use & Care Guide
	8562582	Installation Instructions
	W10042960	Sheet, Cycle Feature
	8528187	Wiring Diagram

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

	677818	Dryer
2	693995	Screw, Hex Head
3	8533971	Screw, 8-18 x 5/16
4	8271365	Cap, End (L.H.)
5	3936144	Connector
6	388326	Screw, Console
7	8533951	Screw, Grounding
8	8271359	Cap, End (R.H.)
9	8274261	Panel, Rear Console
10	8557861	Screen, Lint
11	8536939	Clip, Spring
13	688983	Screw, 8-18 x 5/8
14	94614	Terminal
15	3395683	Connector (Motor)
16	8557930	Top
18	3394427	Clip, Harness
19	3397269	Connector (Timer)
20	3403499	Connector, 2 Position (Gas Valve)
21	3976575	Timer, 60 Hz.
22	357213	Nut, Push-In (2)
23	8299875	Harness, Wiring
24	3977456	Switch, Push-To-Start
25	8566061	Timer Knob Assembly
26	8544895	Bracket, Control
27	8578845	Panel, Control
28	8566065	Knob, Push-To-Start
29	3403498	Connector, 3 Position (Gas Valve)
30	717252	Receptacle (2-Way)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

(Designer White)



CABINET PARTS

For Model: WGD5100SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10–32 x 5/8
2	343641	Screw, 10–16 x 1/2
3	693995	Screw, Hex Head
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	3394975	Plug, Front Panel
7	3396807	Panel, Rear
8	342055	Screw, 8–18 x 1/2
9	3980175	Clamp, Elbow
10	3406102	Door Switch Assembly
11	697773	Screw, 6–20 x 7/8
14	694091	Screw, 8–18 x 3/8
15	3394083	Clip, Front Panel
16	3392100	Foot, Dryer (4)
18	8530603	Cabinet (Includes Illus. 4)
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21	3394895	Front Panel Assembly
23	685203	Clip, Felt Pad
24	3389441	Catch, Door
25	348023	Hinge & Pin Assembly (2)
26	696144	Strike, Door
27	695656	Door, Rear
28	348205	Door, Front
29	686711	Handle, Door
30	8066123	Seal & Bearing Assembly
31	3390734	Seal, Door
32	344020	Cord, Power
33	8066217	Hinge, Top (2)
34	691366	Idler & Pulley Assembly
35	8066065	Belt, Drive
36	348780	Base, Motor
37	3400500	Bolt, 5/16–18 x 3/4
38	8066184	Pulley, 60 Hz.
39	8066206	Motor, 60 Hz.
40	660658	Clamp, Motor
41	3404162	Clamp, Motor (W/Shield)
42	8318272	Burner Assembly, 60 Hz. (Refer To Pages 5 & 6 For Further Breakdown)
43	341029	Clamp, Pipe


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8318272 BURNER ASSEMBLY

For Model: WGD5100SQ0

(Designer White)

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8318272 BURNER ASSEMBLY

For Model: WGD5100SQO
(Designer White)

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8–32 x 5/8)
6	343641	Screw, 10–16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8–18 x 3/8
9		Orifice, Burner Type 1 234826 Type 4 (Butane) 229742 Type 4 (Propane) 234868
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8–32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated


694572 Conversion Kit
(Type 1)
to Type (4) L.P.G.

BA–150

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: WGD5100SQO
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
2	343641	Screw, 10-16 x 1/2
3	3406022	Bracket, Bulkhead
4	3388703	Washer, Support
5	90767	Screw, 8-18 x 3/8
6	3392519	Fuse, Thermal
7	347139	Seal, Lint Chute
8	660039	Thermostat, 150°F(60C)
9	8066086	Drum Hole Plug
10	694089	Wheel, Blower (Includes Illus. 22)

Illus. No.	Part No.	DESCRIPTION
11	8577230	Housing, Blower
12	3398161	Clip
13	489463	Screw, 8-18 x 5/8
14	8530285	Box, Heater
15	3403140	Thermostat, 205°F (96C)
16	280010	Kit, Thermal Cut-Off (Includes Illus. 15)
17	3401707	Wire, Jumper
18	8066048	Funnel, Burner
19	3390647	Screw, 8-18 x 1/2
20	696302	Shield, Exhaust
21	3392247	Pad, Blower Housing

Illus. No.	Part No.	DESCRIPTION
23	690997	Ring, Tri
24	3399506	Shaft, L.H.
25	3399507	Shaft, R.H.
26	3397590	Roller, Support
27	348197	Washer, Support
28	3359452	Nut, 3/8-16
29	8529955	Bulkhead
30	338906	Sensor, Radiant
31	3394508	Ring, Bearing
32	97787	Screw, 11-16 x 3/4
33	8066085	Seal, Rear Drum
34	695584	Drum Assembly
35	342847	Baffle, Drum
36	3976435	Bracket, Support
37	90296	Clip
38	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: WGD5100SQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

ACCESSORY PARTS

279948	Kit, Dryer Repair
8522199	Kit, Dryer Vent Testing
346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)
689790	Dry Rack

PAINT, TOUCH-UP (1/2oz.)

72017	White
-------	-------

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
--------	---------------